

Mounting and Removing HelaGuard Non-Metallic Fittings

HelaGuard plastic fittings are mounted simply, quickly and very securely. They offer exceptionally high pull-off strength and are vibration as well as tamper resistant. They can be removed with a screw driver. HelaGuard plastic fittings can be used again and again.

To mount and remove HelaGuard plastic fittings, follow these simple instructions.



1. If the fitting has been used before, be sure that the slit points to the „on” position. To assemble the fitting, push it on to the end of the conduit as far as possible without forcing it and twist it slightly. The fitting is now securely locked.



3. Move the handle of the screwdriver towards the „off” position. The capnut will rotate slightly. The locking mechanism is now released.



5. Manually rotate the capnut further towards the „off position” as far as possible.



2. To remove the fitting, insert a small screw driver into the slit.



4. Remove the screwdriver.



6. Simply remove the fitting from the end of the conduit.

To re-use HelaGuard plastic fittings, simply turn the capnut back to the „on” position and mount it on to the end of the conduit.